

No.	Code	Name	Description
1	006-0042	FA filter	FA15 installed on the valve directly
2	006-0043	FA filter	FA 15 STRAINER FOR EVR 15, EVRA 3
3	006-0052	FA filter	FA15 installed on the pipe
4	006-0066	FA filter	FA20 installed on the pipe
5	006-0067	FA filter	FA20 installed on the pipe
6	006-1012	FA filter	FA15 installed on the valve directly
7	006-1013	FA filter	FA20 installed on the valve directly
8	006-1107	FA filter spare part	Stay bolt set M12 x 115 TEA /TEAT/TEVA 20
9	006-1135	NRVA spare part	Stay bolt set NRVA 25/32
10	009G0101	Stop valve	BML 6 Shut off valve M/20
11	009G0102	Stop valve	BML 6s Shut off valve M/20
12	009G0122	Stop valve	BML 10s Shut off valve M/20
13	009G0142	Stop valve	BML 12s Shut off valve M/12
14	009G0191	Stop valve	BML 22s Shut off valve M/12
15	009G7023	GBC ball valve	GBC 16s Ball Valve M/25
16	009G7025	GBC ball valve	GBC 22s Ball Valve M/25
17	009G7027	GBC ball valve	GBC 35s Ball Valve M/5
18	009G7050	GBC ball valve	GBC 6s Ball Valve M/25
19	009G7051	GBC ball valve	GBC 10s Ball Valve M/25
20	009G7052	GBC ball valve	GBC 12s Ball Valve M/25
21	009G7053	GBC ball valve	GBC 16s Ball Valve M/25
22	009G7055	GBC ball valve	GBC 22s Ball Valve M/25
23	009G7056	GBC ball valve	GBC 28s Ball Valve M/5
24	009G7057	GBC ball valve	GBC 35s Ball Valve M/5
25	014-0024	SG sight glass	SGI 16s sight glass
26	014-0028	SG sight glass	SGI 19 Sight Glass M/36
27	014-0035	SG sight glass	SGI 10s sight glass
28	014-0036	SG sight glass	SGI 12s sight glass
29	014-0039	SG sight glass	SGI 22s sight glass
30	014-0040	SG sight glass	SGI 6s sight glass
31	014-0041	SG sight glass	SGI 10s sight glass
32	014-0042	SG sight glass	SGI 12s sight glass
33	014-0044	SG sight glass	SGI 16s sight glass
34	014-0045	SG sight glass	SGI 18s sight glass
35	014-0047	SG sight glass	SGI 19s sight glass
36	014-0126	SG sight glass	SGI 10s sight glass
37	014-0127	SG sight glass	SGI 12s sight glass
38	014-0128	SG sight glass	SGI 16s sight glass

39	014-0130	SG sight glass	SGI 22s sight glass
40	014L0182	SG sight glass	SGP 10s N Sight Glass M/25x4
41	014L0184	SG sight glass	SGP 16s N Sight Glass M/28
42	014L0186	SG sight glass	SGP 22s N Sight Glass M/28
43	017-422966	RT spare part	Welding nipple
44	017-436166	RT spare part	Cover with pane for RT
45	017-500166	switch and sensor	RT1A pressure controller
46	017-500366	switch and sensor	RT101 Temperature Control Cap. Tube
47	017-503266	switch and sensor	RT6AW pressure difference controller
48	017-504666	switch and sensor	RT5A pressure controller (automatic reset)
49	017-504766	switch and sensor	RT5A pressure controller (manual reset)
50	017-523766	switch and sensor	RT200 pressure controller, only for Freon
51	017-529566	switch and sensor	RT117 pressure controller, only for Freon
52	017-529866	switch and sensor	RT117E Pressure Control Ex ia IIC T6 Gb
53	017D001466	switch and sensor	RT260A Diff. Press. Control
54	017D001566	switch and sensor	RT260A pressure difference controller, Max working pressure:42bar
55	017D002166	switch and sensor	RT260A pressure difference controller
56	017D002266	switch and sensor	RT260A pressure difference controller
57	017D002366	switch and sensor	RT260A pressure difference controller, Max working pressure:42bar
58	017D002566	switch and sensor	RT252A pressure difference controller
59	017D003666	switch and sensor	RT260AE Diff. Press. Control Ex
60	017L004066	switch and sensor	RT 5AL pressure controller, with dead zone
61	017L004266	switch and sensor	RT117L Pressure Control
62	018F6251	coil	coil, 220-230v, 50Hz, 10w
63	018F6701	coil	coil, 220-230v, 50Hz, 10w
64	018F6707	coil	coil, 24v, 50Hz, 10w
65	018F6714	coil	220V 60Hz 10W
66	018F6732	coil	220-230V 10W 50/60HZ
67	018F6801	coil	220/230V 50Hz 12W
68	018F6814	coil	220V 60Hz 12W
69	018F6827	coil	24V 50/60Hz, 12W
70	018F6857	coil	24V d.c. 20W
71	018F6901	coil	24V 50Hz, 20W
72	018F6905	coil	COIL 230V 50HZ 20W w. box +P
73	020-1018	check valve	NRV 16s Check Valve SW M/24X4
74	020-1020	check valve	NRV 22s Check Valve AW M/18
75	020-1021	check valve	NRV 28s Check Valve AW M/6

76	020-1066	check valve	NRVH 19s Check Valve SW M/28
77	020-1136	pressure difference control valve	NRD 12s Diff. pressure reg. SW M/24X4
78	020-2000	NRVA check valve	NRVA15 straight way check way
79	020-2001	NRVA check valve	NRVA20 straight way check way
80	020-2002	NRVA check valve	NRVA25 straight way check way
81	020-2003	NRVA check valve	NRVA32 straight way check way
82	020-2004	NRVA check valve	NRVA40 straight way check way
83	020-2005	NRVA check valve	NRVA50 straight way check way
84	020-2006	NRVA check valve	NRVA65 straight way check way
85	023U1391	filter drier	48-DM filter drier element, 3pieces/each
86	023U1921	filter drier	48-F filter drier element, 8pieces/each
87	023U4380	filter drier	48-DC filter drier element, 3pieces/each
88	023U4381	filter drier	48-DC filter drier element, 8pieces/each
89	023U7051	filter drier	DCR0487 filter drier, with 1 piece of filter element
90	023U7052	filter drier	DCR0489 filter drier, with 1 piece of filter element
91	023U7053	filter drier	DCR0489 filter drier, with 1 piece of filter element
92	023U7055	filter drier	DCR Filter 04813 Assy.
93	023U7057	filter drier	DCR04817 filter drier, with 1 piece of filter element
94	023U7061	filter drier	DCR09611 filter drier, with 2 pieces of filter element
95	023U7063	filter drier	DCR09613 filter drier, with 2 pieces of filter element
96	023U7064	filter drier	DCR09617 filter drier, with 2 pieces of filter element
97	023U7068	filter drier	DCR14413 filter drier, with 3 pieces of filter element
98	023U7069	filter drier	DCR Filter 14413 Assy.
99	023U7074	filter drier	DCR19217 filter drier, with 4 pieces of filter element
100	023U7076	filter drier	DCR04821 filter drier, with 1 piece of filter element
101	023U7250	filter drier	DCR Filter 0485s Assy.
102	023U7251	filter drier	DCR Filter 0487s Assy.
103	023U7252	filter drier	DCR0489s filter drier, with 1 piece of filter element
104	023U7253	filter drier	DCR0489s filter drier, with 1 piece of filter element
105	023U7254	filter drier	DCR04811s filter drier, with 1 piece of filter element
106	023U7257	filter drier	DCR04817s filter drier, with 1 piece of filter element
107	023U7260	filter drier	DCR Filter 0969s 1 1/8" Assy.
108	023U7261	filter drier	DCR09611s filter drier, with 2 pieces of filter element
109	023U7263	filter drier	DCR09613s filter drier, with 2 pieces of filter element
110	023U7264	filter drier	DCR09617s filter drier, with 2 pieces of filter element
111	023U7274	filter drier	DCR19217s filter drier, with 4 pieces of filter element
112	023Z0035	filter drier	DCL 309S Filter Drier M/8
113	023Z5008	filter drier	DCL163 filter drier, interface:10mm
114	023Z5009	filter drier	DCL164 filter drier, interface:12mm

115	023Z5010	filter drier	DCL165 filter drier, interface:16mm
116	023Z5020	filter drier	DCL053s filter drier, interface:10mm
117	023Z5033	filter drier	FILTER DRIER DCL 165S M/12
118	023Z5034	filter drier	FILTER DRIER DCL 167S M/12
119	023Z5035	filter drier	FILTER DRIER DML 032 M/32
120	023Z5067	filter drier	FILTER DRIER DML 164S M/12
121	027b0080	pilot valve	CVP-XP high pressure constant pressure pilot valve
122	027B0081	valve for C3H6, C3H8 only	SV3E float ball pilot valve
123	027B0087	pilot valve	CVC-XP PILOT VALVE, MWP 52 bar
124	027B1080	pilot valve	CVC (LP) (-0,5 - 9 bar) Pilot Valve
125	027B1100	pilot valve	CVP constant pressure pilot valve, 0-7bar, low pressure type
126	027B1101	pilot valve	CVP constant pressure pilot valve, 0.66-2bar, low pressure type
127	027B1102	pilot valve	CVPP difference pressure pilot valve, 0-7bar, low pressure type
128	027B1120	pilot valve	EVM normal close solenoid pilot valve
129	027B1130	pilot valve	EVM normal open solenoid pilot valve
130	027B1131	valve for C3H6, C3H8 only	EVM normal open solenoid pilot valve, 52bar
131	027B1140	pilot valve	CVQ electronic constant pressure pilot valve, 0-7bar
132	027B1141	pilot valve	CVQ electronic constant pressure pilot valve, 1.7-8bar
133	027B1160	pilot valve	CVP constant pressure pilot valve, 4-22bar, high pressure type
134	027b1161	pilot valve	CVP constant pressure pilot valve, 4-28bar, high pressure type
135	027B1162	pilot valve	CVPP difference pressure pilot valve, 0-7bar, high pressure type
136	027B1164	pilot valve	CVP constant pressure pilot valve, 0.66-7bar, high pressure type
137	027B1268	pilot valve	CVPP difference pressure pilot valve, 4-22bar, high pressure type
138	027B2014	PMFL liquid level regulating valve	SV4 float ball pilot valve, without body
139	027B2021	PMFL liquid level regulating valve	SV1 float ball pilot valve
140	027B2023	PMFL liquid level regulating valve	SV3 float ball pilot valve
141	027B2024	PMFL liquid level regulating valve	SV4 float ball pilot valve
142	027B2027	PMFL liquid level regulating valve	to be installed on SV4, the flange without float ball room

143	027B2053	PMFL liquid level regulating valve	SV3 float ball pilot valve, without body
144	027F0639	PMFL liquid level regulating valve	PMFL 300 Overhaul kit
145	027F1046	PMFL liquid level regulating valve	PM and ICS Blanking plug A+B
146	027F1047	pilot valve	CVH pilot valve seat
147	027F1048	pilot valve	pilot valve external connector
148	027F1090	pilot valve	CVH 15
149	027F2123	flange	DN100 flange
150	027F2124	flange	DN125 flange
151	027F2125	flange	DN150 flange
152	027F2134	PML solenoid valve spare part	PML80-125 manual open device
153	027F3054	PMFL liquid level regulating valve	PMFL80-1 main valve
154	027F3055	PMFL liquid level regulating valve	PMFL80-2 main valve
155	027F3056	PMFL liquid level regulating valve	PMFL80-3 main valve
156	027F3057	PMFL liquid level regulating valve	PMFL80-4 main valve
157	027F3058	PMFL liquid level regulating valve	PMFL80-5 main valve
158	027F3059	PMFL liquid level regulating valve	PMFL80-6 main valve
159	027F3060	PMFL liquid level regulating valve	PMFL80-7 main valve
160	027F3061	PMFL liquid level regulating valve	PMFL125 main valve
161	027F3062	PMFL liquid level regulating valve	PMFL200 main valve
162	027F3063	PMFL liquid level regulating valve	PMFL300 main valve
163	027F3067	PMFH liquid level regulating valve	PMFH 80-4 Liquid level control
164	027F3068	PMFH liquid level regulating valve	PMFH 80-5 high pressure type liquid level regulating main valve
165	027F3069	PMFH liquid level regulating valve	PMFH 80-6 Liquid level control
166	027F3070	PMFH liquid level regulating valve	PMFH 80-7

167	027F3071	PMFH liquid level regulating valve	PMFH 125
168	027F4050	valve for C3H6, C3H8 only	PMFLE80-3 liquid level controlling main valve
169	027F4054	valve for C3H6, C3H8 only	PMFLE80-7 liquid level controlling main valve
170	027H1030	ICV control valve	ICM 20-A 20 DIN
171	027H1031	ICV control valve	ICM 20-B 20 DIN
172	027H1032	ICV control valve	ICM 20-C 20 DIN
173	027H1061	valve for C3H6, C3H8 only	ICS3E 25-10 20 DIN
174	027H1062	valve for C3H6, C3H8 only	ICS3E 25-15 20 DIN
175	027H1145	ICV control valve	ICV 20 20 DIN Valve housing
176	027H1148	ICV control valve	ICV20 valve body
177	027H1163	ICV control valve	ICV20 valve body, DN25
178	027H1166	ICV control valve	ICV20 valve body, interface:DN25
179	027H1180	ICV control valve	ICM20-A function module
180	027H1181	ICV control valve	ICM20-B function module
181	027H1194	ICV control valve	ICM 20 B66 Function module
182	027H2000	ICV control valve	ICM 25-A 25 DIN
183	027H2016	ICV control valve	ICM 25-A 40 DIN
184	027H2020	ICV control valve	ICS 5-1 25 DIN
185	027h2028	ICV control valve	ICS25-5 whole valve, one pilot interface
186	027H2030	ICV control valve	ICS 10-1 25 DIN
187	027H2040	ICV control valve	ICS 25-15 1 PILOT VALVE 25D(1")
188	027H2048	ICV control valve	ICS1 15-1 20 DIN
189	027H2050	ICV control valve	ICS1 25-20 25 DIN
190	027H2058	ICV control valve	ICS1 25-20 20 DIN
191	027H2060	ICV control valve	ICS1 25-25 25 DIN
192	027H2090	ICV control valve	ICS3 25-15 25 DIN
193	027H2100	ICV control valve	ICS3 25-20 25 DIN
194	027H2120	ICV control valve	ICS 25 valve body, D □
195	027H2121	ICV control valve	ICS 25 valve body, A □
196	027H2128	ICV control valve	ICS 25 valve body, DN20
197	027H2129	ICV control valve	ICV 25 32 DIN Valve housing
198	027H2135	ICV control valve	ICS 25 valve body, DN40
199	027H2172	ICV control valve	ICS25 top cover, one pilot interface
200	027H2173	ICV control valve	ICS25 top cover, three pilot interface
201	027H2179	valve for C3H6, C3H8 only	ICS3E 25-25 25 DIN
202	027H2180	ICV control valve	ICM25-A function module
203	027H2200	ICV control valve	ICS 25-25 function module
204	027H2202	ICV control valve	ICS 25-10 function module

205	027H2203	ICV control valve	ICS 25-15 function module
206	027H2204	ICV control valve	ICS 25-20 function module
207	027H2215	oil pressure regulating valve	ICS 1 25-20 main valve+ CVPP (HP)pressure difference pilot valve
208	027H2216	oil pressure regulating valve	ICS 1 25-25 main valve+ CVPP (HP)pressure difference pilot valve
209	027H3000	ICV control valve	ICM 32-A 32 DIN
210	027H3001	ICV control valve	ICM 32-B 32 DIN
211	027H3020	ICV control valve	ICS1 32 32 DIN
212	027H3030	ICV control valve	ICS3-32 whole valve
213	027H3040	ICLX two step opening solenoid valve	ICLX32,with pilot valve
214	027H3120	ICV control valve	ICS 32 valve body, D □
215	027H3121	ICV control valve	ICS 32 valve body, A □
216	027H3125	ICV control valve	ICV 32 40 DIN Valve housing
217	027H3172	ICV control valve	ICS32 top cover, one pilot interface
218	027H3173	ICV control valve	ICS32 top cover, three pilot interface
219	027H3200	ICV control valve	ICS 32 function module
220	027H4000	ICV control valve	ICM 40-A 40 DIN
221	027H4010	ICV control valve	ICM 40-A 50 DIN
222	027H4020	ICV control valve	ICS1 40 40 DIN
223	027H4030	ICV control valve	ICS3-40 whole valve
224	027H4040	ICLX two step opening solenoid valve	ICLX40,with pilot valve
225	027H4120	ICV control valve	ICS 40 valve body, D □
226	027H4121	ICV control valve	ICS 40 valve body, A □
227	027H4126	ICV control valve	ICV 40 50 DIN Valve housing
228	027H4172	ICV control valve	ICS40 top cover, one pilot interface
229	027H4173	ICV control valve	ICS40 top cover, three pilot interface
230	027H4180	ICV control valve	ICM40-A function module
231	027H4200	ICV control valve	ICS 40 function module
232	027H5020	ICV control valve	ICS1 50 50 DIN
233	027H5030	ICV control valve	ICS3-50 whole valve
234	027H5040	ICLX two step opening solenoid valve	ICLX50,with pilot valve
235	027H5120	ICV control valve	ICS 50 valve body, D □
236	027H5121	ICV control valve	ICS 50 valve body, A □
237	027H5124	ICV control valve	ICV 50 65 DIN Valve housing
238	027H5172	ICV control valve	ICS50 top cover, one pilot interface
239	027H5173	ICV control valve	ICS50 top cover, three pilot interface

240	027H5180	ICV control valve	ICM50-A function module
241	027H5200	ICV control valve	ICS 50 function module
242	027H6010	ICV control valve	ICM 65-A 65 D STR
243	027H6020	ICV control valve	ICS1 65 65 DIN
244	027H6030	ICV control valve	ICS3-65 whole valve
245	027H6040	ICLX two step opening solenoid valve	ICLX65, with pilot valve
246	027H6120	ICV control valve	ICS 65 valve body, D □
247	027H6126	ICV control valve	ICV 65 80 DIN Valve housing
248	027H6172	ICV control valve	ICS 65 Top cover 1 pilot
249	027H6173	ICV control valve	ICS65 top cover, three pilot interface
250	027H6181	ICV control valve	ICM 65B Function module
251	027H6200	ICV control valve	ICS 65 function module
252	027h7120	ICV control valve	ICS3-100 whole valve
253	027H7140	ICV control valve	ICS, DN 125, DIN connection
254	027H7147	ICLX two step opening solenoid valve	ICLX100, with pilot valve
255	027H7157	ICLX two step opening solenoid valve	ICLX125, with pilot valve
256	027H7160	ICS servo main valve	ICS150 whole valve, three pilot interface
257	027H7167	ICLX two step opening solenoid valve	ICLX150, with pilot valve
258	027H8020	ICV control valve	ICS3-80 whole valve
259	027H8040	ICLX two step opening solenoid valve	ICLX 65 80 DIN
260	027H9075	ICV control valve	ICAD 600 Actuator
261	027H9077	ICV control valve	ICAD 1200
262	027L1228	flange	PMFL/H80 flange
263	027L2335	flange	PMFL/H125 flange
264	027L3018	ICF multifunction combination valve	ICF20-6-3
265	027L3020	ICF multifunction combination valve	ICF20-6-3(25D)
266	027L3021	ICF multifunction combination valve	ICF 20-6-3 (32D)
267	027L3067	ICF multifunction combination valve	ICF20-4-9
268	027L4016	ICF multifunction combination valve	ICF 40-6-1B
269	027L4020	ICF multifunction combination valve	ICF25-6-3A

		valve	
270	027L4024	ICF multifunction combination valve	ICF32-6-3A
271	027L4029	ICF multifunction combination valve	ICF32-6-3B
272	027L4034	ICF multifunction combination valve	ICF40-6-3B (40D)
273	027L4063	ICF multifunction combination valve	ICF 25-4-9 25D
274	027L4067	ICF multifunction combination valve	ICF32-4-9
275	027L4072	ICF multifunction combination valve	ICF40-4-9
276	027L4121	ICF multifunction combination valve	ICF 25-6-15A
277	027L4126	ICF multifunction combination valve	ICF 32-6-15B
278	027L4130	ICF multifunction combination valve	ICF40-6-15B
279	027L4133	ICF multifunction combination valve	ICF32-4-8
280	027N1025	flange	PHT85 flange
281	027N1026	flange	Flange Set 1 in. weld
282	027N1112	flange	NRVA, EVRA10 flange
283	027N1115	flange	NRVA, EVRA15 flange
284	027N1120	flange	NRVA, EVRA20 flange
285	027N1220	flange	DN20 flange
286	027N1225	flange	DN25 flange
287	027N1230	flange	DN32 flange
288	027N2332	flange	DN32 flange
289	027N2340	flange	DN40 flange
290	027N2440	flange	DN40 flange
291	027N2450	flange	DN50 flange
292	027N2550	flange	DN50 flange
293	027N2565	flange	Welding Flanges 2 1/2 in
294	027N2665	flange	DN65 flange
295	027N2680	flange	DN80 flange
296	032F1204	EVR solenoid valve body	EVR3 valve body, 10mm
297	032F1206	EVR solenoid valve body	EVR3 valve body, 6mm
298	032F1209	EVR solenoid valve body	EVR6 valve body, 12mm

299	032F1212	EVR solenoid valve body	EVR6 valve body, 10mm
300	032F1213	EVR solenoid valve body	EVR6 valve body, 10mm
301	032F1214	EVR solenoid valve body	EVR10 valve body, 16mm
302	032F1217	EVR solenoid valve body	EVR10 valve body, 12mm
303	032F1218	EVR solenoid valve body	EVR10 valve body, 12mm
304	032F1225	EVR solenoid valve body	EVR15 valve body, 22mm
305	032F1227	EVR solenoid valve body	EVR15 valve body, 16mm
306	032F1228	EVR solenoid valve body	EVR15 valve body, 16mm
307	032F1236	EVR solenoid valve body	EVR6 valve body, 12mm
308	032F1240	EVR solenoid valve body	EVR20 valve body, 22mm
309	032F1244	EVR solenoid valve body	EVR20 valve body, 28mm
310	032F1245	EVR solenoid valve body	EVR20 valve body, 28mm
311	032F1254	EVR solenoid valve body	EVR20 valve body, 22mm
312	032F1269	EVR solenoid valve body	EVR20 valve body, normal open, 28mm
313	032F2200	EVR solenoid valve body	EVR25 valve body
314	032F2205	EVR solenoid valve body	EVR25 valve body, DN28
315	032F2207	EVR solenoid valve body	EVR25 valve body, DN35
316	032F3050	EVRA/T solenoid valve body	EVRA3 valve body
317	032F3267	EVR solenoid valve body	EVR22 valve body, 35mm
318	032F3270	EVR solenoid valve body	EVR15 valve body, DN22, normal open
319	032F5438	EVR S solenoid valve body	EVRST 20 Solenoid valve
320	032F6210	EVRA/T solenoid valve body	EVRA10 valve body
321	032F6214	EVRA/T solenoid valve body	EVRA10 valve body
322	032F6215	EVRA/T solenoid valve body	EVRA15 valve body
323	032F6216	EVRA/T solenoid valve body	EVRA15 valve body
324	032F6219	EVRA/T solenoid valve body	EVRA20 valve body
325	032F6220	EVRA/T solenoid valve body	EVRA20 valve body, with alternating current coil
326	032F6221	EVRA/T solenoid valve body	EVRA20 valve body
327	032F6225	EVRA/T solenoid valve body	EVRA25 valve body
328	032F6277	EVR solenoid valve spare part	SPARE PART KIT
329	032F8011	pilot valve	EVM Pilot valve, 65 bar MWP Multi 20
330	032F8029	valve for C3H6, C3H8 only	EVME solenoid pilot valve
331	032U7122	water solenoid valve	Valve EV220B 20B G 34E N0000
332	032U7132	water solenoid valve	Valve EV220B 32B G 114E NC000
333	032U7140	water solenoid valve	Valve EV220B 40B G 112E NC000
334	032U7150	water solenoid valve	EV220B water solenoid valve
335	032U7173	water solenoid valve	EV220B DN32
336	032U7174	water solenoid valve	EV220B DN40
337	032U7175	water solenoid valve	EV220B DN50

338	032U7181	water solenoid valve	EV220B DN20
339	034G0505	electronic expansion valve	ETS 100 ElecExpValve 158x158 SG
340	034G2201	wiring on electronic expansion valve	Wire 4x0.5 2m w M12 female
341	034L0094	valve for C3H6, C3H8 only	KVR22 pressure regulating valve
342	034L0097	valve for C3H6, C3H8 only	KVR15 pressure regulating valve
343	034L0099	valve for C3H6, C3H8 only	KVR28 pressure regulating valve
344	034L0100	pressure regulating valve	KVR 35 Pressure regulator
345	034L0147	pressure regulating valve	KVC 15 Pressure regulator
346	042H1103	EVR solenoid valve body	EVR 32 Valve ODF-ODF 1 5/8in Single.
347	042H1104	EVR solenoid valve body	EVR32 valve body, without manual operation
348	042H1105	EVR solenoid valve body	EVR32 valve body, DN35
349	042H1106	EVR solenoid valve body	EVR32 valve body, DN35, without manual operation
350	042h1107	EVR solenoid valve body	EVR32 valve body, DN42
351	042H1110	EVR solenoid valve body	EVR40 valve body, without manual operation
352	042H1111	EVR solenoid valve body	EVR40 valve body, DN54
353	042H1113	EVR solenoid valve body	EVR40 valve body, DN42
354	042H1126	EVRA/T solenoid valve body	EVRA32 valve body, DN32
355	042H1128	EVRA/T solenoid valve body	EVRA40 valve body, DN40
356	042H1131	EVRA/T solenoid valve body	EVRA32 valve body, DN40
357	042H1132	EVRA/T solenoid valve body	EVRA40 valve body, DN50
358	042h1141	EVRA solenoid valve	EVRA32 valve body, DN40
359	042H1142	EVRA/T solenoid valve body	EVRA40 valve body, DN41
360	042H2103	electronic expansion valve	AKVA20-3 Valve Weld con. 1 1/4in Single
361	042H2104	electronic expansion valve	AKVA20-4 Valve Weld con. 1 1/2in Single
362	042H2105	electronic expansion valve	AKVA20-5 Valve Weld con. 2in Single.
363	060-116066	switch and sensor	KP1A pressure control
364	060-117191	switch and sensor	KP5 pressure control
365	060-117766	switch and sensor	KP5 pressure control, only for Freon
366	060-123066	switch and sensor	KP5A pressure control
367	060-519066	switch and sensor	KP6W
368	060B017466	switch and sensor	MP55A Diff. Pressure Control
369	060G1125	switch and sensor	Sensor MBS 3000-2011-1AB04, 4-20mA
370	060G2104	switch and sensor	AKS33 pressure sensor
371	060G2105	switch and sensor	AKS33 pressure sensor
372	060G2106	switch and sensor	AKS33 pressure sensor
373	060G2107	switch and sensor	AKS33 pressure sensor
374	060G2108	switch and sensor	AKS33 pressure sensor
375	060G2109	switch and sensor	AKS33 pressure sensor

376	060G2110	switch and sensor	AKS33 pressure sensor
377	060G2111	switch and sensor	AKS33 pressure sensor
378	060G3631	pressure sensor	AKS 3000 pressure sensor, only for CO2
379	064G6583	pressure sensor	Sensor MBS 1900-8911-A0GB04
380	067B2708	TE thermostatic expansion valve	TEX12-17, No.5 valve element
381	067B2709	TE thermostatic expansion valve	TE 12 Orifice 06
382	067B2710	TE thermostatic expansion valve	TE 12 Orifice 07
383	067B2771	TE thermostatic expansion valve	TEX20-32.5, No.8 valve element
384	067B2788	TE thermostatic expansion valve	TE 5 Orifice 0,5
385	067B2789	TE thermostatic expansion valve	TEX5-5.5, No.1 valve element
386	067B2790	TE thermostatic expansion valve	TEX5-7.5, No.2 valve element
387	067B2791	TE thermostatic expansion valve	TEX5-10, No.3 valve element
388	067B2792	TE thermostatic expansion valve	TEX5-13, No.4 valve element
389	067B3207	TE thermostatic expansion valve	TEX 12 thermometer bulb, NM series
390	067B3209	TE thermostatic expansion valve	TEX 12 thermometer bulb, N series
391	067B3210	TE thermostatic expansion valve	TEX 12 thermometer bulb, N series
392	067B3211	TE thermostatic expansion valve	TEX 12 thermometer bulb, B series, with MOP
393	067B3212	TE thermostatic expansion valve	TEX 12 thermometer bulb, B series, with MOP
394	067B3213	TE thermostatic expansion valve	TEX 12 thermometer bulb, NL series, with MOP
395	067B3227	TE thermostatic expansion valve	TEX 12 thermometer bulb, N series, with MOP
396	067B3249	TE thermostatic expansion valve	TEX 5 thermometer bulb, NM series, with MOP
397	067B3250	TE thermostatic expansion valve	TEX 5 thermometer bulb, N series
398	067B3251	TE thermostatic expansion valve	TEX 5 thermometer bulb, B series, with MOP
399	067B3253	TE thermostatic expansion valve	TEX 5 thermometer bulb, NL series, with MOP
400	067B3263	TE thermostatic expansion valve	TEX 5 thermometer bulb, B series
401	067B3267	TE thermostatic expansion valve	TEX 5 thermometer bulb, N series, with MOP
402	067B3273	TE thermostatic expansion valve	TEX 20 thermometer bulb, NM series, with MOP
403	067B3274	TE thermostatic expansion valve	TEX 20 thermometer bulb, N series
404	067B3275	TE thermostatic expansion valve	TEX 20 thermometer bulb, NL series, with MOP
405	067B3276	TE thermostatic expansion valve	TEX 20 thermometer bulb, B series, with MOP
406	067B3286	TE thermostatic expansion valve	TEX 20 thermometer bulb, N series
407	067B3290	TE thermostatic expansion valve	TEX 20 thermometer bulb, N series
408	067B3303	thermostatic expansion valve	PHT therm element
409	067B3318	TE thermostatic expansion valve	PHTN thermometer bulb
410	067B3342	TE thermostatic expansion valve	TES 5 Element N
411	067B3343	TE thermostatic expansion valve	TES 5 Element BMOP
412	067B3345	TE thermostatic expansion valve	TES 12 Element NMMOP
413	067B3346	TE thermostatic expansion valve	TES12 thermometer bulb, N series
414	067B3347	TE thermostatic expansion valve	TES12 thermometer bulb, N series

415	067B3349	TE thermostatic expansion valve	TES 12 Element BMOP
416	067B3352	TE thermostatic expansion valve	TES20 thermometer bulb, N series
417	067B3357	TE thermostatic expansion valve	TES 5 Element NMMOP
418	067B4007	TE thermostatic expansion valve	TE 5 Valve Body SS
419	067B4009	TE thermostatic expansion valve	TE 5 Valve Body SA
420	067B4011	TE thermostatic expansion valve	TE 5 Valve Body SA
421	067B4016	TE thermostatic expansion valve	TE 12/20 & TQ12/20 Valve Body SS
422	067B4020	TE thermostatic expansion valve	TE 12 Valve Body SS
423	067B4021	TE thermostatic expansion valve	TE 12/20 & TQ12/20 Valve Body SS
424	067B4026	TE thermostatic expansion valve	TE 12 Valve Body FS
425	067B4032	TE thermostatic expansion valve	TE 5 Valve Body SS
426	067B4033	TE thermostatic expansion valve	TE 5 Valve Body SS
427	067B4035	TE thermostatic expansion valve	TE 5 Valve Body SS
428	067G2701	TE thermostatic expansion valve	TEX55-44.5, No.10 valve element
429	067G2704	TE thermostatic expansion valve	TEX55-54, No.11 valve element
430	067G2705	TE thermostatic expansion valve	TE 55 Orifice 9B
431	067G2707	TE thermostatic expansion valve	TEX55-65.5, No.12 valve element
432	067G2710	TE thermostatic expansion valve	TEX55-80, No.13 valve element
433	067G3205	TE thermostatic expansion valve	TEX 55 thermometer bulb, N series
434	067G3206	TE thermostatic expansion valve	TEX 55 thermometer bulb, NM series, with MOP
435	067G3207	TE thermostatic expansion valve	TEX 55 thermometer bulb, B series, with MOP
436	067G3209	TE thermostatic expansion valve	TEX 55 thermometer bulb, N series
437	067G3217	TE thermostatic expansion valve	TEX 55 thermometer bulb, B series, with MOP
438	067G3220	TE thermostatic expansion valve	TEX 55 thermometer bulb, N series, with MOP
439	067G3222	TE thermostatic expansion valve	TEN 55 Element N
440	067G3223	TE thermostatic expansion valve	TEN 55 Element NMOP
441	067G3301	TE thermostatic expansion valve	TES 55 Element N
442	067G3302	TE thermostatic expansion valve	TES55 thermometer bulb, N series
443	067G4001	TE thermostatic expansion valve	TE 55 Valve Body SS
444	067G4003	TE thermostatic expansion valve	TE 55 Valve Body SS
445	067G4004	TE thermostatic expansion valve	TE 55 Valve Body SA
446	067N2156	TGE thermostatic expansion valve	TGEX 7,5 Expansion Valve Solder M/12
447	067N2157	TGE thermostatic expansion valve	TGEX 11 Expansion Valve Solder M/12
448	067N2158	TGE thermostatic expansion valve	TGEX 11 Expansion Valve Solder M/12
449	067N2162	TGE thermostatic expansion valve	TGEX 15 Expansion Valve Solder M/8
450	067N2163	TGE thermostatic expansion valve	TGEX 18 Expansion Valve Solder M/8
451	067N2168	TGE thermostatic expansion valve	TGEX 30 Expansion Valve Solder M/6
452	068-2002	T2 & TE2 thermostatic expansion valve	OX valve element

453	068-2003	T2 & TE2 thermostatic expansion valve	00 valve element
454	068-2006	T2 & TE2 thermostatic expansion valve	03 valve element
455	068-2007	T2 & TE2 thermostatic expansion valve	04 valve element
456	068-2008	T2 & TE2 thermostatic expansion valve	05 valve element
457	068-2009	T2 & TE2 thermostatic expansion valve	06 valve element
458	068-2010	T2 & TE2 thermostatic expansion valve	01 valve element
459	068-2015	T2 & TE2 thermostatic expansion valve	02 valve element
460	068-2089	T2 & TE2 thermostatic expansion valve	0X valve element
461	068-2090	T2 & TE2 thermostatic expansion valve	00 valve element
462	068-2091	T2 & TE2 thermostatic expansion valve	01 valve element
463	068-2092	T2 & TE2 thermostatic expansion valve	02 valve element
464	068-2093	T2 & TE2 thermostatic expansion valve	03 valve element
465	068-2094	T2 & TE2 thermostatic expansion valve	04 valve element
466	068-2095	T2 & TE2 thermostatic expansion valve	05 valve element
467	068-2096	T2 & TE2 thermostatic expansion valve	06 valve element
468	068B0017	Accessory bag	Accessory bag
469	068B0018	Accessory bag	Accessory bag
470	068B0676	Accessory bag	Seal kit
471	068F1170	electronic expansion valve	AKV10-4 Valve ODF-ODF 3/8-1/2in Multi 18
472	068F3267	electronic expansion valve	AKVA10-7 Valve Weld con. 1/2-3/4in Mu18
473	068F5000	electronic expansion valve	AKV15-1 Valve ODF-ODF 3/4in Single.
474	068F5015	electronic expansion valve	AKV15-4 Valve ODF-ODF 1 1/8in Single
475	068F5020	electronic expansion valve	AKVA15-1 pulse electronic expansion valve
476	068F5023	electronic expansion valve	AKVA15-2 pulse electronic expansion valve
477	068F5026	electronic expansion valve	AKVA15-3 pulse electronic expansion valve
478	068F5029	electronic expansion valve	AKVA15-4 pulse electronic expansion valve

479	068G2055	TEA/T expansion valve	TEA20-12 valve element
480	068G3250	TEA/T expansion valve	TEA20 thermometer bulb
481	068G6001	TEA/T expansion valve	TEA20-2 expansion valve, evaporative temperature:-50~0
482	068G6002	TEA/T expansion valve	TEA20-3 expansion valve, evaporative temperature:-50~0
483	068G6003	TEA/T expansion valve	TEA20-5 expansion valve, evaporative temperature:-50~0
484	068G6004	TEA/T expansion valve	TEA20-8 expansion valve, evaporative temperature:-50~0
485	068G6005	TEA/T expansion valve	TEA20-12 expansion valve, evaporative temperature:-50~0
486	068G6006	TEA/T expansion valve	TEA20-20 expansion valve, evaporative temperature:-50~0
487	068G6007	TEA/T expansion valve	TEA85-33 expansion valve, evaporative temperature:-50~0
488	068G6008	TEA/T expansion valve	TEA85-55 expansion valve, evaporative temperature:-50~0
489	068G6068	TEA/T expansion valve	TEAT 20-20 spray valve
490	068G6070	TEA/T expansion valve	TEAT 85-33 spray valve
491	068G6126	TEA/T expansion valve	TEAT 20-5 spray valve
492	068G6135	TEA/T expansion valve	TEA20-20 expansion valve, evaporative temperature:-20~30
493	068G6139	TEA/T expansion valve	TEA20-8 expansion valve, evaporative temperature:-20~30
494	068G6140	TEA/T expansion valve	TEA20-12 expansion valve, evaporative temperature:-20~30
495	068Z3174	T2 & TE2 thermostatic expansion valve	TEB 2 expansion valve body
496	068Z3202	T2 & TE2 thermostatic expansion valve	TF 2 expansion valve body
497	068Z3204	T2 & TE2 thermostatic expansion valve	TEF 2 expansion valve body
498	068Z3206	T2 & TE2 thermostatic expansion valve	TX 2 expansion valve body
499	068Z3207	T2 & TE2 thermostatic expansion valve	TX 2 expansion valve body
500	068Z3208	T2 & TE2 thermostatic expansion valve	TX 2 expansion valve body
501	068Z3209	T2 & TE2 thermostatic expansion valve	TEX 2 expansion valve body
502	068Z3210	T2 & TE2 thermostatic expansion valve	TEX 2 expansion valve body
503	068Z3211	T2 & TE2 thermostatic expansion valve	TEX 2 expansion valve body
504	068Z3212	T2 & TE2 thermostatic expansion valve	TY 2 expansion valve body
505	068Z3213	T2 & TE2 thermostatic expansion valve	TY 2 expansion valve body
506	068Z3215	T2 & TE2 thermostatic expansion valve	TEY 2 expansion valve body

507	068Z3216	T2 & TE2 thermostatic expansion valve	TEY 2 expansion valve body
508	068Z3220	T2 & TE2 thermostatic expansion valve	TF 2 expansion valve body
509	068Z3221	T2 & TE2 thermostatic expansion valve	TEF 2 expansion valve body
510	068Z3222	T2 & TE2 thermostatic expansion valve	TF 2 expansion valve body
511	068Z3223	T2 & TE2 thermostatic expansion valve	TEF 2 expansion valve body
512	068Z3224	T2 & TE2 thermostatic expansion valve	TX 2 expansion valve body
513	068Z3225	T2 & TE2 thermostatic expansion valve	TEX 2 expansion valve body
514	068Z3226	T2 & TE2 thermostatic expansion valve	TX 2 expansion valve body
515	068Z3227	T2 & TE2 thermostatic expansion valve	TEX 2 expansion valve body
516	068Z3228	T2 & TE2 thermostatic expansion valve	TX 2 expansion valve body
517	068Z3229	T2 & TE2 thermostatic expansion valve	TEX 2 expansion valve body
518	068Z3230	T2 & TE2 thermostatic expansion valve	TY 2 expansion valve body
519	068Z3231	T2 & TE2 thermostatic expansion valve	TEY 2 expansion valve body
520	068Z3232	T2 & TE2 thermostatic expansion valve	TY 2 expansion valve body
521	068Z3233	T2 & TE2 thermostatic expansion valve	TEY 2 expansion valve body
522	068Z3234	T2 & TE2 thermostatic expansion valve	TY 2 expansion valve body
523	068Z3235	T2 & TE2 thermostatic expansion valve	TEY 2 expansion valve body
524	068Z3236	T2 & TE2 thermostatic expansion valve	TF 2 expansion valve body
525	068Z3237	T2 & TE2 thermostatic expansion valve	TEF 2 expansion valve body
526	068Z3276	T2 & TE2 thermostatic expansion valve	TX 2 expansion valve body
527	068Z3277	T2 & TE2 thermostatic expansion valve	TEX 2 expansion valve body

528	068Z3280	T2 & TE2 thermostatic expansion valve	TF 2 expansion valve body
529	068Z3281	T2 & TE2 thermostatic expansion valve	TX 2 expansion valve body
530	068Z3282	T2 & TE2 thermostatic expansion valve	TY 2 expansion valve body
531	068Z3283	T2 & TE2 thermostatic expansion valve	TEF 2 expansion valve body
532	068Z3284	T2 & TE2 thermostatic expansion valve	TEX 2 expansion valve body
533	068Z3285	T2 & TE2 thermostatic expansion valve	TEY 2 expansion valve body
534	068Z3286	T2 & TE2 thermostatic expansion valve	TF 2 expansion valve body
535	068Z3287	T2 & TE2 thermostatic expansion valve	TX 2 expansion valve body
536	068Z3290	T2 & TE2 thermostatic expansion valve	TEX 2 expansion valve body
537	068Z3292	T2 & TE2 thermostatic expansion valve	TY 2 expansion valve body
538	068Z3293	T2 & TE2 thermostatic expansion valve	TEY 2 expansion valve body
539	068Z3295	T2 & TE2 thermostatic expansion valve	TEY 2 expansion valve body
540	068Z3301	T2 & TE2 thermostatic expansion valve	TF 2 expansion valve body
541	068Z3302	T2 & TE2 thermostatic expansion valve	TX 2 expansion valve body
542	068Z3303	T2 & TE2 thermostatic expansion valve	TY 2 expansion valve body
543	068Z3304	T2 & TE2 thermostatic expansion valve	TEF 2 expansion valve body
544	068Z3305	T2 & TE2 thermostatic expansion valve	TEX 2 expansion valve body
545	068Z3306	T2 & TE2 thermostatic expansion valve	TEY 2 expansion valve body
546	068Z3308	T2 & TE2 thermostatic expansion valve	TX 2 expansion valve body
547	068Z3309	T2 & TE2 thermostatic expansion valve	TY 2 expansion valve body
548	068Z3311	T2 & TE2 thermostatic expansion valve	TEX 2 expansion valve body

549	068Z3312	T2 & TE2 thermostatic expansion valve	TEY 2 expansion valve body
550	068Z3316	T2 & TE2 thermostatic expansion valve	TEY 2 expansion valve body
551	068Z3319	T2 & TE2 thermostatic expansion valve	TX 2 expansion valve body
552	068Z3320	T2 & TE2 thermostatic expansion valve	TEX 2 expansion valve body
553	068Z3332	T2 & TE2 thermostatic expansion valve	TX 2 expansion valve body
554	068Z3333	T2 & TE2 thermostatic expansion valve	TEX 2 expansion valve body
555	068Z3346	T2 & TE2 thermostatic expansion valve	TN 2 expansion valve body
556	068Z3347	T2 & TE2 thermostatic expansion valve	TN 2 expansion valve body
557	068Z3348	T2 & TE2 thermostatic expansion valve	TEN 2 expansion valve body
558	068Z3349	T2 & TE2 thermostatic expansion valve	TEN 2 expansion valve body
559	068Z3357	T2 & TE2 thermostatic expansion valve	TX 2 expansion valve body
560	068Z3359	T2 & TE2 thermostatic expansion valve	TEX 2 expansion valve body
561	068Z3361	T2 & TE2 thermostatic expansion valve	TX 2 expansion valve body
562	068Z3363	T2 & TE2 thermostatic expansion valve	TEX 2 expansion valve body
563	068Z3366	T2 & TE2 thermostatic expansion valve	TX 2 expansion valve body
564	068Z3367	T2 & TE2 thermostatic expansion valve	TEX 2 expansion valve body
565	068Z3369	T2 & TE2 thermostatic expansion valve	TN 2 expansion valve body
566	068Z3370	T2 & TE2 thermostatic expansion valve	TEN 2 expansion valve body
567	068Z3383	T2 & TE2 thermostatic expansion valve	TN 2 expansion valve body
568	068Z3384	T2 & TE2 thermostatic expansion valve	TN 2 expansion valve body
569	068Z3385	T2 & TE2 thermostatic expansion valve	TEN 2 expansion valve body

570	068Z3386	T2 & TE2 thermostatic expansion valve	TEN 2 expansion valve body
571	068Z3387	T2 & TE2 thermostatic expansion valve	TN 2 expansion valve body
572	068Z3388	T2 & TE2 thermostatic expansion valve	TN 2 expansion valve body
573	068Z3389	T2 & TE2 thermostatic expansion valve	TEN 2 expansion valve body
574	068Z3390	T2 & TE2 thermostatic expansion valve	TEN 2 expansion valve body
575	068Z3392	T2 & TE2 thermostatic expansion valve	TEN 2 expansion valve body
576	068Z3393	T2 & TE2 thermostatic expansion valve	TN 2 expansion valve body
577	068Z3400	T2 & TE2 thermostatic expansion valve	TS 2 expansion valve body
578	068Z3401	T2 & TE2 thermostatic expansion valve	TS 2 expansion valve body
579	068Z3402	T2 & TE2 thermostatic expansion valve	TS 2 expansion valve body
580	068Z3403	T2 & TE2 thermostatic expansion valve	TES 2 expansion valve body
581	068Z3404	T2 & TE2 thermostatic expansion valve	TES 2 expansion valve body
582	068Z3405	T2 & TE2 thermostatic expansion valve	TES 2 expansion valve body
583	068Z3406	T2 & TE2 thermostatic expansion valve	TS 2 expansion valve body
584	068Z3407	T2 & TE2 thermostatic expansion valve	TES 2 expansion valve body
585	068Z3408	T2 & TE2 thermostatic expansion valve	TS 2 expansion valve body
586	068Z3409	T2 & TE2 thermostatic expansion valve	TES 2 expansion valve body
587	068Z3410	T2 & TE2 thermostatic expansion valve	TS 2 expansion valve body
588	068Z3411	T2 & TE2 thermostatic expansion valve	TES 2 expansion valve body
589	068Z3414	T2 & TE2 thermostatic expansion valve	TS 2 expansion valve body
590	068Z3415	T2 & TE2 thermostatic expansion valve	TES 2 expansion valve body

591	068Z3416	T2 & TE2 thermostatic expansion valve	TS 2 expansion valve body
592	068Z3417	T2 & TE2 thermostatic expansion valve	TES 2 expansion valve body
593	068Z3418	T2 & TE2 thermostatic expansion valve	TS 2 expansion valve body
594	068Z3419	T2 & TE2 thermostatic expansion valve	TES 2 expansion valve body
595	068Z3420	T2 & TE2 thermostatic expansion valve	TS 2 expansion valve body
596	068Z3421	T2 & TE2 thermostatic expansion valve	TES 2 expansion valve body
597	068Z3422	T2 & TE2 thermostatic expansion valve	TES 2 expansion valve body
598	068Z3423	T2 & TE2 thermostatic expansion valve	TS 2 expansion valve body
599	068Z3424	T2 & TE2 thermostatic expansion valve	TES 2 expansion valve body
600	068Z3425	T2 & TE2 thermostatic expansion valve	TS 2 expansion valve body
601	068Z3426	T2 & TE2 thermostatic expansion valve	TES 2 expansion valve body
602	068Z3427	T2 & TE2 thermostatic expansion valve	TS 2 expansion valve body
603	068Z3428	T2 & TE2 thermostatic expansion valve	TES 2 expansion valve body
604	068Z3429	T2 & TE2 thermostatic expansion valve	TS 2 expansion valve body
605	068Z3430	T2 & TE2 thermostatic expansion valve	TES 2 expansion valve body
606	068Z3435	T2 & TE2 thermostatic expansion valve	TS 2 expansion valve body
607	068Z3436	T2 & TE2 thermostatic expansion valve	TS 2 expansion valve body
608	068Z3437	T2 & TE2 thermostatic expansion valve	TES 2 expansion valve body
609	068Z3445	T2 & TE2 thermostatic expansion valve	TES 2 expansion valve body
610	068Z3446	T2 & TE2 thermostatic expansion valve	TEZ 2 expansion valve body
611	068Z3447	T2 & TE2 thermostatic expansion valve	TEZ 2 expansion valve body

612	068Z3462	T2 & TE2 thermostatic expansion valve	TY 2 expansion valve body
613	068Z3496	T2 & TE2 thermostatic expansion valve	TZ 2 expansion valve body
614	068Z3501	T2 & TE2 thermostatic expansion valve	TEZ 2 expansion valve body
615	068Z3502	T2 & TE2 thermostatic expansion valve	TZ 2 expansion valve body
616	068Z3503	T2 & TE2 thermostatic expansion valve	TEZ 2 expansion valve body
617	068Z3514	T2 & TE2 thermostatic expansion valve	TZ 2 expansion valve body
618	068Z3515	T2 & TE2 thermostatic expansion valve	TEZ 2 expansion valve body
619	068Z3516	T2 & TE2 thermostatic expansion valve	TZ 2 expansion valve body
620	068Z3517	T2 & TE2 thermostatic expansion valve	TEZ 2 expansion valve body
621	068Z3518	T2 & TE2 thermostatic expansion valve	TEB 2 expansion valve body
622	068Z7008	T2 & TE2 thermostatic expansion valve	TEB 2 expansion valve
623	068Z7009	T2 & TE2 thermostatic expansion valve	TEB 2 expansion valve
624	068Z7012	T2 & TE2 thermostatic expansion valve	TEB 2 expansion valve body
625	084B7060	regulator	EKC361 temperature controller
626	084B7067	regulator	EKC347 liquid level controller
627	084B7086	regulator	EKC315A evaporator over heat controller
628	084B7104	regulator	EKC331refrigeration capacity controller
629	084B7250	regulator	EKC 312, Controller, Expansion Valve
630	084B8040	regulator	EKD 316, Controller, ETS Valve Interface
631	084H4520	liquid level sensor	liquid lever sensor AKS4100U
632	084H4521	liquid level sensor	liquid lever sensor AKS4100U
633	084H4525	liquid level sensor	AKS 4100U Level Sensor Coaxial 30"
634	084H4526	liquid level sensor	AKS 4100U Level Sensor Coaxial 45"
635	084H4529	liquid level sensor	AKS 4100U Level Sensor Coaxial 85"
636	084H4532	liquid level sensor	AKS 4100U Coaxial 45" with HMI
637	084H4533	liquid level sensor	AKS 4100U Level Sensor Coaxial 55"
638	084H4534	liquid level sensor	AKS 4100U Level Sensor Coaxial 65"
639	084H4548	liquid level sensor	AKS 4100/4100U Display unit

640	084N0005	switch and sensor	AKS11 temperature sensor
641	084N2003	switch and sensor	AKS21m temperature sensor
642	084N2008	switch and sensor	Sensor AKS 21A Surface Sensor
643	084N2016	switch and sensor	AKS21w temperature sensor
644	084N2017	switch and sensor	Sensor AKS 21 W
645	148B3761	SVA stop valve	SVA-DL 250 right angle stop valve (hand wheel)
646	148B3762	SVA stop valve	SVA-DL 250 right angle stop valve(bonnet)
647	148B3765	SVA stop valve	SVA-DH 250 right angle stop valve (hand wheel)
648	148B3770	SVA stop valve	SVA-DL 300 right angle stop valve(bonnet)
649	148B3771	SVA stop valve	SVA-DL 300 right angle stop valve (hand wheel)
650	148B3772	SVA stop valve	SVA-DL 300 right angle stop valve(bonnet)
651	148B3773	SVA stop valve	SVA-DL 300 right angle stop valve (hand wheel)
652	148B3776	SVA stop valve	SVA-DH 300 right angle stop valve(bonnet)
653	148B3778	needle valve	SNV-ST G1/2 MAN STOP NEEDLE VALVE
654	148B4184	needle valve spare part	Weld Nipple DN 6 D SVA/SNV
655	148B4296	STC stop valve spare part	STC15-25 stop valve, position A sealing spare part
656	148B4297	STC stop valve spare part	STC32-40 stop valve, position A sealing spare part
657	148B4309	STC stop valve spare part	STC15-25 stop valve, position B2 sealing spare part
658	148B4310	STC stop valve spare part	STC32-40stop valve, position B2 sealing spare part
659	148B4311	STC stop valve spare part	STC50-65 stop valve, position B2 sealing spare part
660	148B4312	STC stop valve spare part	STC80-100 stop valve, position B2 sealing spare part
661	148B4600	STC stop valve	STC15 right angle stop valve(bonnet)
662	148B4601	STC stop valve	STC15 right angle stop valve (hand wheel)
663	148B4622	STC stop valve	STC15 straight stop valve(bonnet)
664	148B4623	STC stop valve	STC15 straight stop valve (hand wheel)
665	148B4602	STC stop valve	STC20 right angle stop valve(bonnet)
666	148B4603	STC stop valve	STC20 right angle stop valve (hand wheel)
667	148B4624	STC stop valve	STC20 straight stop valve(bonnet)
668	148B4625	STC stop valve	STC20 straight stop valve (hand wheel)
669	148B4604	STC stop valve	STC25 right angle stop valve(bonnet)
670	148B4605	STC stop valve	STC25 right angle stop valve (hand wheel)
671	148B4626	STC stop valve	STC25 straight stop valve(bonnet)
672	148B4627	STC stop valve	STC25 straight stop valve (hand wheel)
673	148B4606	STC stop valve	STC32 right angle stop valve(bonnet)
674	148B4607	STC stop valve	STC32 right angle stop valve (hand wheel)
675	148B4628	STC stop valve	STC32 straight stop valve(bonnet)
676	148B4629	STC stop valve	STC32 straight stop valve (hand wheel)
677	148B4608	STC stop valve	STC40 right angle stop valve(bonnet)

678	148B4609	STC stop valve	STC40 right angle stop valve (hand wheel)
679	148B4630	STC stop valve	STC40 straight stop valve(bonnet)
680	148B4631	STC stop valve	STC40 straight stop valve (hand wheel)
681	148B4610	STC stop valve	STC50 right angle stop valve(bonnet)
682	148B4611	STC stop valve	STC50 right angle stop valve (hand wheel)
683	148B4632	STC stop valve	STC50 straight stop valve(bonnet)
684	148B4633	STC stop valve	STC50 straight stop valve (hand wheel)
685	148B4612	STC stop valve	STC65 right angle stop valve(bonnet)
686	148B4613	STC stop valve	STC65 right angle stop valve (hand wheel)
687	148B4634	STC stop valve	STC65 straight stop valve(bonnet)
688	148B4635	STC stop valve	STC65 straight stop valve (hand wheel)
689	148B4614	STC stop valve	STC80 right angle stop valve(bonnet)
690	148B4615	STC stop valve	STC80 right angle stop valve (hand wheel)
691	148B4636	STC stop valve	STC80 straight stop valve(bonnet)
692	148B4637	STC stop valve	STC80 straight stop valve (hand wheel)
693	148B4616	STC stop valve	STC100 right angle stop valve(bonnet)
694	148B4617	STC stop valve	STC100 right angle stop valve (hand wheel)
695	148B4638	STC stop valve	STC100 straight stop valve(bonnet)
696	148B4639	STC stop valve	STC100 straight stop valve (hand wheel)
697	148B4618	STC stop valve	STC125 right angle stop valve(bonnet)
698	148B4619	STC stop valve	STC125 right angle stop valve (hand wheel)
699	148B4640	STC stop valve	STC125 straight stop valve(bonnet)
700	148B4641	STC stop valve	STC125 straight stop valve (hand wheel)
701	148B4620	STC stop valve	STC150 right angle stop valve(bonnet)
702	148B4621	STC stop valve	STC150 right angle stop valve (hand wheel)
703	148B4642	STC stop valve	STC150 straight stop valve(bonnet)
704	148B4643	STC stop valve	STC150 straight stop valve (hand wheel)
705	148B4645	STC stop valve	STC15 right angle stop valve (hand wheel)
706	148B4667	STC stop valve	STC15 straight stop valve (hand wheel)
707	148B4647	STC stop valve	STC20 right angle stop valve (hand wheel)
708	148B4669	STC stop valve	STC20 straight stop valve (hand wheel)
709	148B4649	STC stop valve	STC25 right angle stop valve (hand wheel)
710	148B4671	STC stop valve	STC25 straight stop valve (hand wheel)
711	148B4651	STC stop valve	STC32 right angle stop valve (hand wheel)
712	148B4673	STC stop valve	STC32 straight stop valve (hand wheel)
713	148B4653	STC stop valve	STC40 right angle stop valve (hand wheel)
714	148B4675	STC stop valve	STC40 straight stop valve (hand wheel)
715	148B4655	STC stop valve	STC50 right angle stop valve (hand wheel)
716	148B4677	STC stop valve	STC50 straight stop valve (hand wheel)

717	148B4657	STC stop valve	STC65 right angle stop valve (hand wheel)
718	148B4679	STC stop valve	STC65 straight stop valve (hand wheel)
719	148B4659	STC stop valve	STC80 right angle stop valve (hand wheel)
720	148B4681	STC stop valve	STC80 straight stop valve (hand wheel)
721	148B4661	STC stop valve	STC100 right angle stop valve (hand wheel)
722	148B4683	STC stop valve	STC100 straight stop valve (hand wheel)
723	148B4663	STC stop valve	STC125 right angle stop valve (hand wheel)
724	148B4685	STC stop valve	STC125 straight stop valve (hand wheel)
725	148B4665	STC stop valve	STC150 right angle stop valve (hand wheel)
726	148B4687	STC stop valve	STC150 straight stop valve (hand wheel)
727	148B4644	STC stop valve	STC 15 right angle stop valve(bonnet)
728	148B4666	STC stop valve	STC 15 right angle stop valve(bonnet)
729	148B4646	STC stop valve	STC 20 right angle stop valve(bonnet)
730	148B4668	STC stop valve	STC 20 right angle stop valve(bonnet)
731	148B4648	STC stop valve	STC 25 right angle stop valve(bonnet)
732	148B4670	STC stop valve	STC 25 right angle stop valve(bonnet)
733	148B4650	STC stop valve	STC 32 right angle stop valve(bonnet)
734	148B4672	STC stop valve	STC 32 right angle stop valve(bonnet)
735	148B4652	STC stop valve	STC 40 right angle stop valve(bonnet)
736	148B4674	STC stop valve	STC 40 right angle stop valve(bonnet)
737	148B4654	STC stop valve	STC 50 right angle stop valve(bonnet)
738	148B4676	STC stop valve	STC 50 right angle stop valve(bonnet)
739	148B4656	STC stop valve	STC 65 right angle stop valve(bonnet)
740	148B4678	STC stop valve	STC 65 right angle stop valve(bonnet)
741	148B4658	STC stop valve	STC 80 right angle stop valve(bonnet)
742	148B4680	STC stop valve	STC 80 right angle stop valve(bonnet)
743	148B4660	STC stop valve	STC 100 right angle stop valve(bonnet)
744	148B4682	STC stop valve	STC 100 right angle stop valve(bonnet)
745	148B4662	STC stop valve	STC 125 right angle stop valve(bonnet)
746	148B4684	STC stop valve	STC 125 right angle stop valve(bonnet)
747	148B4664	STC stop valve	STC 150 right angle stop valve(bonnet)
748	148B4686	STC stop valve	STC 150 right angle stop valve(bonnet)
750	148B4488	STC stop valve spare part	STC50 stop valve, position A sealing spare part
751	148B4490	STC stop valve spare part	STC80 stop valve, position A sealing spare part
752	148B4491	STC stop valve spare part	STC100 stop valve, position A sealing spare part
753	148B5000	SVL stop valve	SVA-S 6 D ANG H-WHEEL
754	148B5001	SVL stop valve	SVA-S 6 D ANG CAP
755	148B5010	SVL stop valve	SVA-S 6 D STR H-WHEEL
756	148B5011	SVL stop valve	SVA-S 6 D STR CAP

757	148B5100	SVL stop valve	SVA-S 10 D ANG H-WHEEL
758	148B5101	SVL stop valve	SVA-S 10 D ANG CAP
759	148B5102	REG-S regulating valve	REG-SA 10 D ANG
760	148B5103	REG-S regulating valve	REG-SB 10 D ANG
761	148B5104	REG-S regulating valve	REG-SA 10 D STR
762	148B5105	REG-S regulating valve	REG-SB 10 D STR
763	148B5110	SVL stop valve	SVA-S 10 D STR H-WHEEL
764	148B5111	SVL stop valve	SVA-S 10 D STR CAP
765	148B5130	SVL stop valve	SVA-S 10 A STR STOP VALVE H-WHEEL
766	148B5200	SVL stop valve	SVA-S 15 D ANG H-WHEEL
767	148B5201	SVL stop valve	SVA-S 15 D ANG CAP
768	148B5203	REG-S regulating valve	REG-SB 15 A ANG VALVE CAP
769	148B5208	SCA-X stop check valve	SCA-X 15 D ANG
770	148B5210	SVL stop valve	SVA-S 15 D STR H-WHEEL
771	148B5211	SVL stop valve	SVA-S 15 D STR CAP
772	148B5212	REG-S regulating valve	REG-SA 15 A STR VALVE CAP
773	148B5226	REG-S regulating valve	REG-SA 15 D ANG
774	148B5227	REG-S regulating valve	REG-SB 15 D ANG
775	148B5228	REG-S regulating valve	REG-SA 15 D STR
776	148B5229	REG-S regulating valve	REG-SB 15 D STR
777	148B5231	SVL stop valve	SVA-S 15 A STR CAP
778	148B5236	CHV-X check valve	CHV-X 15 D ANG
779	148B5240	SVL stop valve	SVA-L 15 D ANG STOP VALVE H-WHEEL
780	148B5242	FIA52bar filter	FIA 15 D ANG
781	148B5243	FIA52bar filter	FIA 15 D STR
782	148B5247	FIA52bar filter	FIA 15 A STR FILTER HOUSING
783	148B5250	SVL stop valve	SVA-L 15 D STR STOP VALVE H-WHEEL
784	148B5300	SVL stop valve	SVA-S 20 D ANG H-WHEEL
785	148B5301	SVL stop valve	SVA-S 20 D ANG CAP
786	148B5308	SCA-X stop check valve	SCA-X 20 D ANG
787	148B5310	SVL stop valve	SVA-S 20 D STR H-WHEEL
788	148B5311	SVL stop valve	SVA-S 20 D STR CAP
789	148B5313	REG-S regulating valve	REG-SB 20 A STR VALVE CAP
790	148B5326	REG-S regulating valve	REG-SA 20 D ANG
791	148B5327	REG-S regulating valve	REG-SB 20 D ANG
792	148B5328	REG-S regulating valve	REG-SA 20 D STR
793	148B5329	REG-S regulating valve	REG-SB 20 D STR
794	148B5331	SVL stop valve	SVA-S 20 A STR STOP VALVE CAP
795	148B5336	CHV-X check valve	CHV-X 20 D ANG

796	148B5340	SVL stop valve	SVA-L 20 D ANG STOP VALVE H-WHEEL
797	148B5342	FIA52bar filter	FIA 20 D ANG
798	148B5343	FIA52bar filter	FIA 20 D STR
799	148B5347	FIA52bar filter	FIA 20 A STR FILTER HOUSING
800	148B5400	SVL stop valve	SVA-S 25 D ANG H-WHEEL
801	148B5401	SVL stop valve	SVA-S 25 D ANG CAP
802	148B5408	SCA-X stop check valve	SCA-X 25 D ANG
803	148B5410	SVL stop valve	SVA-S 25 D STR H-WHEEL
804	148B5411	SVL stop valve	SVA-S 25 D STR CAP
805	148B5412	REG-S regulating valve	REG-SA 25 A STR VALVE CAP
806	148B5421	SVL stop valve	SVA-S 25 A ANG CAP
807	148B5426	REG-S regulating valve	REG-SA 25 D ANG
808	148B5427	REG-S regulating valve	REG-SB 25 D ANG
809	148B5428	REG-S regulating valve	REG-SA 25 D STR
810	148B5429	REG-S regulating valve	REG-SB 25 D STR
811	148B5431	SVL stop valve	SVA-S 25 A STR CAP
812	148B5436	CHV-X check valve	CHV-X 25 D ANG
813	148B5440	SVL stop valve	SVA-L 25 D ANG STOP VALVE H-WHEEL
814	148B5442	FIA52bar filter	FIA 25 D ANG
815	148B5443	FIA52bar filter	FIA 25 D STR
816	148B5450	SVL stop valve	SVA-L 25 D STR STOP VALVE H-WHEEL
817	148B5500	SVL stop valve	SVA-S 32 D ANG H-WHEEL
818	148B5501	SVL stop valve	SVA-S 32 D ANG CAP
819	148B5508	SCA-X stop check valve	SCA-X 32 D ANG
820	148B5510	SVL stop valve	SVA-S 32 D STR H-WHEEL
821	148B5511	SVL stop valve	SVA-S 32 D STR CAP
822	148B5513	REG-S regulating valve	REG-SB 32 A STR VALVE CAP
823	148B5526	REG-S regulating valve	REG-SB 32 D ANG
824	148B5527	REG-S regulating valve	REG-SA 32 D ANG
825	148B5528	REG-S regulating valve	REG-SA 32 D STR
826	148B5529	REG-S regulating valve	REG-SB 32 D STR
827	148B5536	CHV-X check valve	CHV-X 32 D ANG
828	148B5540	SVL stop valve	SVA-L 32 D ANG STOP VALVE H-WHEEL
829	148B5543	FIA52bar filter	FIA 32 D ANG
830	148B5544	FIA53bar filter	FIA 32 D STR
831	148B5600	SVL stop valve	SVA-S 40 D ANG H-WHEEL
832	148B5601	SVL stop valve	SVA-S 40 D ANG CAP
833	148B5608	SCA-X stop check valve	SCA-X 40 D ANG
834	148B5610	SVL stop valve	SVA-S 40 D STR H-WHEEL

835	148B5611	SVL stop valve	SVA-S 40 D STR CAP
836	148B5621	SVL stop valve	SVA-S 40 A ANG CAP
837	148B5624	FIA52bar filter	FIA 40 D ANG
838	148B5625	FIA52bar filter	FIA 40 D STR
839	148B5626	REG-S regulating valve	REG-SB 40 D ANG
840	148B5627	REG-S regulating valve	REG-SA 40 D ANG
841	148B5628	REG-S regulating valve	REG-SB 40 D STR
842	148B5629	REG-S regulating valve	REG-SA 40 D STR
843	148B5631	SVL stop valve	SVA-S 40 A STR CAP
844	148B5636	CHV-X check valve	CHV-X 40 D ANG
845	148B5640	SVL stop valve	SVA-L 40 D ANG STOP VALVE H-WHEEL
846	148B5650	SVL stop valve	SVA-L 40 D STR STOP VALVE H-WHEEL
847	148B5700	SVL stop valve	SVA-S 50 D ANG H-WHEEL
848	148B5701	SVL stop valve	SVA-S 50 D ANG CAP
849	148B5702	SCA-X stop check valve	SCA-X 50 D ANG
850	148B5710	SVL stop valve	SVA-S 50 D STR H-WHEEL
851	148B5711	SVL stop valve	SVA-S 50 D STR CAP
852	148B5712	FIA52bar filter	FIA 50 D ANG
853	148B5713	FIA52bar filter	FIA 50 D STR
854	148B5721	SVL stop valve	SVA-S 50 A ANG STOP VALVE CAP
855	148B5726	REG-S regulating valve	REG-SB 50 D ANG
856	148B5731	SVL stop valve	SVA-S 50 A STR STOP VALVE CAP
857	148B5736	CHV-X check valve	CHV-X 50 D ANG
858	148B5800	SVL stop valve	SVA-S 65 D ANG H-WHEEL
859	148B5801	SVL stop valve	SVA-S 65 D ANG CAP
860	148B5803	SCA-X stop check valve	SCA-X 65 D ANG
861	148B5810	SVL stop valve	SVA-S 65 D STR H-WHEEL
862	148B5811	SVL stop valve	SVA-S 65 D STR CAP
863	148B5812	FIA52bar filter	FIA 65 D ANG
864	148B5813	FIA52bar filter	FIA 65 D STR
865	148B5821	SVL stop valve	SVA-S 65 A ANG STOP VALVE CAP
866	148B5826	REG-S regulating valve	REG-SB 65 D ANG
867	148B5831	SVL stop valve	SVA-S 65 A STR STOP VALVE CAP
868	148B5838	CHV-X check valve	CHV-X 65 D ANG
869	148B5900	SVL stop valve	SVA-S 80 D ANG H-WHEEL
870	148B5901	SVL stop valve	SVA-S 80 D ANG CAP
871	148B5902	SCA-X stop check valve	SCA-X 80 D ANG
872	148B5905	FIA52bar filter	FIA 80 D ANG
873	148B5906	FIA52bar filter	FIA 80 D STR

874	148B5910	SVL stop valve	SVA-S 80 D STR H-WHEEL
875	148B5911	SVL stop valve	SVA-S 80 D STR CAP
876	148B5931	SVL stop valve	SVA-S 80 A STR STOP VALVE CAP
877	148B5936	CHV-X check valve	CHV-X 80 D ANG
878	148B6000	SVL stop valve	SVA-S 100 D ANG H-WHEEL
879	148B6001	SVL stop valve	SVA-S 100 D ANG CAP
880	148B6002	SCA-X stop check valve	SCA-X 100 D ANG
881	148B6006	FIA52bar filter	FIA 100 D ANG
882	148B6007	FIA52bar filter	FIA 100 D STR
883	148B6010	SVL stop valve	SVA-S 100 D STR H-WHEEL
884	148B6011	SVL stop valve	SVA-S 100 D STR CAP
885	148B6021	SVL stop valve	SVA-S 100 A ANG STOP VALVE CAP
886	148B6031	SVL stop valve	SVA-S 100 A STR STOP VALVE CAP
887	148B6036	CHV-X check valve	CHV-X 100 D ANG
888	148B6100	SVL stop valve	SVA-S 125 D ANG H-WHEEL
889	148B6101	SVL stop valve	SVA-S 125 D ANG CAP
890	148B6102	SCA-X stop check valve	SCA-X 125 D ANG
891	148B6105	FIA52bar filter	FIA 125 D ANG
892	148B6106	FIA52bar filter	FIA 125 D STR
893	148B6110	SVL stop valve	SVA-S 125 D STR H-WHEEL
894	148B6111	SVL stop valve	SVA-S 125 D STR CAP
895	148B6131	SVL stop valve	SVA-S 125 A STR STOP VALVE CAP
896	148B6136	CHV-X check valve	CHV-X 125 D ANG
897	148B6200	SVL stop valve	SVA-S 150 D ANG H-WHEEL
898	148B6201	SVL stop valve	SVA-S 150 D ANG CAP
899	148B6202	FIA52bar filter	FIA 150 D ANG
900	148B6203	FIA52bar filter	FIA 150 D STR
901	148B6210	SVL stop valve	SVA-S 150 D STR H-WHEEL
902	148B6211	SVL stop valve	SVA-S 150 D STR CAP
903	148B6221	SVL stop valve	SVA-S 150 A ANG STOP VALVE CAP
904	148B6231	SVL stop valve	SVA-S 150 A STR STOP VALVE CAP
905	148B6300	SVL stop valve	SVA-S 200 D ANG H-WHEEL
906	148B6301	SVL stop valve	SVA-S 200 D ANG CAP
907	148B6302	FIA52bar filter	FIA 200 D ANG
908	148B6303	FIA52bar filter	FIA 200 D STR
909	148B6310	SVL stop valve	SVA-S 200 D STR H-WHEEL
910	148B6311	SVL stop valve	SVA-S 200 D STR CAP
911	148B6321	SVL stop valve	SVA-S 200 A ANG STOP VALVE CAP
912	148F3005	double seat safety valve seat	valve seat DSV1 D25/ND20

913	148F3006	double seat safety valve seat	valve seat DSV2 FD20/ND20
914	148F3009	double seat safety valve seat	valve seat DSV2 FD25/FD25
915	148F3010	double seat safety valve seat	DSV2 FD32/FD5, DUAL STOPVALVE+KIT
916	148F3011	double seat safety valve seat	valve seat DSV2 FD32/FD32
917	148F3020	safety valve	SFV20 flange and gasket
918	148F3021	safety valve connecting accessory	Flanges+Gaskets set for SFV 25
919	148F3213	safety valve	SFA15 safety valve, setting pressure:13bar
920	148F3218	safety valve	SFA 15 T 218 SAFETY VALVE 18 BAR
921	148F3219	safety valve	SFA15 safety valve, setting pressure:19bar
922	148G3151	GPLX two step opening solenoid valve	GPLX-80-D, 2 step servo valve
923	148G3152	GPLX two step opening solenoid valve	GPLX-100-D, 2 step servo valve
924	148G3153	GPLX two step opening solenoid valve	GPLX125, pneumatic right angle type two step open solenoid valve
925	148G3195	stainless steel valve	OFV-SS 25 D ANG OVER FLOW VALVE 52BAR
926	148G3588	other products	KDC 65 multiple function compressor valve
927	148G3604	other products	KDC 150 multiple function compressor valve
928	148H3119	FIA filter screen	FIA80 filter screen, 150u
929	148H3121	FIA filter screen	FIA80 filter screen, 500u
930	148H3122	FIA filter screen	FIA15-20 filter screen, 100u
931	148H3123	FIA filter screen	FIA25-40 filter screen, 100u
932	148H3124	FIA filter screen	FIA15-20 filter screen, 150u
933	148H3125	FIA filter screen	FIA25-40 filter screen, 150u
934	148H3127	FIA filter screen	FIA-INS 25-40 250my FILTER ELEMENT
935	148H3128	FIA filter screen	FIA15-20 filter screen, 150u
936	148H3129	FIA filter screen	FIA-INS 25-40 500my FILTER ELEMENT
937	148H3130	FIA filter screen	FIA50 filter screen, 150u
938	148H3131	FIA filter screen	FIA65 filter screen, 150u
939	148H3132	FIA filter screen	FIA-INS 100 150MY FILTER ELEMENT
940	148H3133	FIA filter screen	FIA-INS 125 150my FILTER ELEMENT
941	148H3135	FIA filter screen	FIA200 filter screen, 150u
942	148H3138	FIA filter screen	FIA50 filter screen, 250u
943	148H3139	FIA filter screen	FIA65 filter screen, 250u
944	148H3144	FIA filter screen	FIA50 filter screen, 500u
945	148H3145	FIA filter screen	FIA-INS 65 500my FILTER ELEMENT
946	148H3146	FIA filter screen	FIA-INS 100 500my FILTER ELEMENT
947	148H3147	FIA filter screen	FIA-INS 125 500my FILTER ELEMENT
948	148h3157	FIA filter screen	FIA50 filter screen, 100u

949	148H3194	liquid level switch	AKS38 liquid level switch
950	148H3200	maintenance spare part	REPAIR-KIT FOR AKS 38
951	148H3202	maintenance spare part	SPARE PART, SWITCH-BOX, AKS 38
952	148H3272	fast oil discharge valve	QDV 15 D QUICK CLOSING OIL DRAIN VALVE
953	148H3362	oil temperature control valve	ORV 80 D H3 Valve housing with cover
954	148H3401	oil temperature control valve	ORV 25 ANSI H1 Valve housing with cover
955	148H3402	oil temperature control valve	ORV 40 DIN H2 Valve housing with cover
956	148H3405	oil temperature control valve	ORV 40 ANSI H2 Valve housing with cover
957	148H3406	oil temperature control valve	ORV 50 DIN H2 Valve housing with cover
958	148H3409	oil temperature control valve	ORV 65 DIN H3 Valve housing with cover
959	148H3453	safety valve connecting accessory	EXTERNAL CONNECTION BSV/POV
960	148H3463	oil temperature control valve	ORV THERMOSTAT H1 49° C/120° F
961	148H3464	oil temperature control valve	ORV THERMOSTAT H2 49° C/120° F
962	148H3468	oil temperature control valve	ORV THERMOSTAT H3 43° C/110° F
963	2412+183	overflow valve	OFV20 right angle overflow valve
964	2412+184	overflow valve	OFV25 right angle overflow valve
965	2416+150	safety valve	SFV20 safety valve, setting pressure:13bar
966	2416+151	safety valve	SFV20 safety valve, setting pressure:18bar
967	2416+153	safety valve	SFV 25 T 213 SAFETY VALVE 13 BAR
968	2416+154	safety valve	SFV25 safety valve, setting pressure:18bar
969	2416+221	safety valve	BSV 8 T 216 SAFETY VALVE 16 BAR
970	2416+256	safety valve	SFV20 safety valve, setting pressure:12bar
971	2416+261	safety valve	SFV20 safety valve, setting pressure:19bar
972	2416+272	safety valve	SFV25 safety valve, setting pressure:19bar
973	2416+313	safety valve	BSV 8 safety valve, setting pressure:17bar
974	2417+047	safety valve	POV 600, inner safety valve
975	2417+232	safety valve	POV 600 BUTT WELD, DIN DN40 ANG
976	2512+050	plate type liquid level meter	Range:335mm
977	2512+053	plate type liquid level meter	Range:995mm
978	2512+054	plate type liquid level meter	Range:1145mm
979	2512+055	plate type liquid level meter	